
BT SIP Trunk Configuration Guide

This document covers service specific configuration required for interoperability with the BT SIP Trunk service. Anything which could be considered as normal CUCM configuration (such as dial plan, device pools etc.) are not within the scope of this document unless a specific configuration parameter is required in order to ensure the greatest level of interoperability with the BT SIP Trunk service.

This configuration guidance can be split into five distinct areas:

1. CUCM service parameters required for correct SIP behaviour (with regards to the BT SIP Trunk platform)
2. SIP Trunk configuration specific parameters
3. CUBE device configuration required for correct SIP behaviour (with regards to the BT SIP Trunk platform)
4. Hardware resources required for correct interaction of CUCM and the BT SIP Trunk platform
5. End device specific parameters required for correct operation

It should be further noted that the document reflects the configuration of the test environment used to execute the BT SIP Trunk platform compliance testing. Only configuration which is non-default will be covered.

1 Service Parameters

Cluster-wide parameters for the “Cisco CallManager” service:

Parameter	Default	New Setting
Transfer On-Hook Enabled	False	True
SIP Min-SE Value	1800	450
Fail Call Over SIP Trunk if MTP Allocation Fails	False	True

More detailed information on these changes is as follows:

Transfer On-Hook Enabled

This parameter is set to “**True**” in order to enable the blind-transfer capabilities that were required during compliance testing.

SIP Min-SE Value

By default, a SIP:INVITE message sent from the BT SIP Trunk platform to CUCM had a Minimum Session Expiry (Min-SE) value set to 450ms. CUCM's default value is 1800ms. If CUCM receives a message with a Min-SE value lower than the configured service parameter it will reject the message with a SIP:422 – Session Time Too Small error. In order to prevent this, the service parameter was reduced to “**450ms**” to accommodate the requests coming from the platform.

Fail Call Over SIP Trunk if MTP Allocation Fails

By default if MTP is required for a connection CUCM will attempt to allocate one from its configured resources, however if one is unavailable it will still allow the call to proceed without allocating the MTP. For interaction with the BT SIP Trunk, MTP is sometimes required for correct device / feature operation such as DTMF tone generation with RFC-2833 non-compliant devices. As such, MTP must be allocated to guarantee a consistent and reliable service will be received by the caller and so if MTP resource is unavailable the call should not proceed. Hence the parameter is set to “**True**”.

2 SIP Trunk Configuration Specific Parameters

The configuration of a SIP Trunk in CUCM can be split into three distinct categories:

1. SIP Profile
2. SIP Trunk Security Profile
3. SIP Trunk Configuration

SIP Profile Configuration

When interfacing between a Cisco CUBE device and CUCM where the CUBE performs the Early Offer / Delayed Offer interworking to establish early media without the need for MTP, a default

SIP Profile is mostly used. However, one core parameter needs to be configured on a dedicated SIP profile as follows:

Parameter	Default Setting	New Setting
SIP Rel1XX Options	Disabled	Send PRACK for all 1xx Messages

More detailed information on this change is as follows:

SIP Rel1XX Options

This option governs the behaviour of CUCM regarding provisional acknowledgements to 1xx series session progress messages. By default CUCM will do nothing. With an external device providing Early Offer / Delayed Offer interworking for CUCM such that Early Media can be negotiated without the need for CUCM to perform Early Offer itself, CUCM is required to respond to a 1xx series message with media information.

By enabling this option, when the CUBE device alters the SIP signalling headers of a SIP 183 message, CUCM will respond with a PRovisional ACKnowledgement (PRACK) to the CUBE (and, by proxy, the BT SIP Trunk platform) with details of supported / preferred media streams and destination, thus establishing an Early Media stream.

Early Media is required for the successful playback of network messages (such as Caller Waiting, or a switched-off mobile) and hence it is required for CUCM to respond.

SIP Trunk Security Profile Configuration

A default SIP Trunk Security Profile is used, the core configuration parameters are:

Parameter	New Setting
Device Security Mode	Non Secure
Incoming Transport Type	TCP+UDP
Outgoing Transport Type	TCP
Enable Digest Authentication	Unchecked
Nonce Validity Time (mins)	600
X.509 Subject Name	<Blank>
Incoming Port	5060
Enable Application Level Authorization	Unchecked
Accept Presence Subscription	Unchecked
Accept Out-of-Dialog REFER	Unchecked
Accept Unsolicited Notification	Unchecked
Accept Replaces Header	Unchecked
Transmit Security Status	Unchecked

The only real point to note is the Outgoing Transport Type – this is set to TCP rather than the platform default of UDP. As a Cisco CUBE device is employed then there is no reason to deviate from the default TCP mechanism of CUCM; furthermore, TCP mechanisms allow faster failure detection by CUCM (realising the TCP session is down rather than waiting for signalling timeout) so potentially allows a faster failover between multiple CUBE devices should they be deployed.

All other parameters essentially remain at default.

SIP Trunk Configuration

SIP Trunk specific configuration parameters that need to be changed from default or must be a specific parameter are:

Parameter	Default Setting	New / Mandatory Setting
Media Termination Point Required	Unchecked	Unchecked
Call Routing Information – Asserted-Identity	Checked	Checked
Call Routing Information – Asserted-Type	Default	PAI
SIP Trunk Security Profile	-- Not Selected --	<Pre-configured profile>
SIP Profile	-- Not Selected --	<Pre-configured profile>
DTMF Signalling Method	No Preference	RFC 2833

More detailed information on these changes is as follows:

Media Termination Point Required

Forcing MTP on for a SIP Trunk will restrict the codec supported on the trunk to a singular codec (either G.711 or G.729a). If enabled then the codec must be restricted to the lowest common denominator (i.e. G.729a). Therefore, to maintain maximum flexibility it must be disabled to enable the widest possible interoperability along with codec selection.

Call Routing Information – Asserted-Identity / Asserted-Type

By default the BT SIP Trunk platform requires that the Privacy-Asserted-ID field in SIP messaging is populated to correctly populate caller identity, particularly for emergency calls. Therefore to ensure that CUCM populates this field this should be set from Default to “**PAI**”.

SIP Trunk Security Profile / SIP Profile

Both a SIP Trunk Security profile and a SIP Profile need to be configured to reflect the BT SIP Trunk platform requirements (as detailed previously). These then need to be applied to the specific trunks when configured.

DTMF Signalling Method

The BT SIP Trunk platform requires that all DTMF signalling uses the RFC 2833 specified mechanism. Therefore to ensure that CUCM adheres to this requirement the SIP Trunk should be configured accordingly and the DTMF Signalling Method changed from No Preference to “**RFC 2833**”.

3 CUBE Device Configuration

The configuration of the CUBE device can be split into three distinct categories:

1. Voice Services and General Protocol Behaviour
2. Voice Classes
3. Dial Peers

Voice Services and General Protocol Behaviour

The first part of the configuration sets up how the CUBE device behaves with SIP signalling, with the following sample configuration:

```
voice service voip
 ip address trusted list
 ipv4 <SBC 1 IP>
 ipv4 <SBC 2 IP>
 ipv4 <SBC 3 IP>
 ipv4 <SBC 4 IP>
 allow-connections sip to sip
 fax protocol t38 version 0 ls-redundancy 5 hs-redundancy 2 fallback none
 sip
 min-se 450 session-expires 900
 session refresh
 error-passthru
 asserted-id pai
 options-ping 60
 midcall-signaling passthru
!
!
!
sip-ua
 retry invite 3
 timers trying 350
!
!
```

The above configuration alters the SIP signalling timers and privacy settings ensuring that:

- Session timers allow the lower-than-default platform session refresh timers
- Error signalling is passed through the CUBE to CUCM
- Privacy-Asserted-Identity headers are allowed (a platform requirement)
- The CUBE device can probe SBC's and dynamically shut-down corresponding dial peers when the SBC is out of service
- Fail over a call in 2.5 seconds rather than the default of 32 seconds when an SBC fails while waiting for the OPTIONS pings to take the dial peer out of service.

Voice Classes

The second part of the configuration deals with filtering preferred / allowed codecs and manipulating the outbound SIP signalling headers on a per-call basis:

```
voice class codec 1
  codec preference 1 g711alaw
  codec preference 2 g711ulaw
  codec preference 3 g729r8
!
voice class sip-profiles 100
  request INVITE sip-header SIP-Req-URI modify "; SIP/2.0" ";user=phone SIP/2.0"
  request REINVITE sip-header SIP-Req-URI modify "; SIP/2.0" ";user=phone SIP/2.0"
  request INVITE sip-header SIP-Req-URI modify " SIP/2.0" ";user=phone SIP/2.0"
  request REINVITE sip-header SIP-Req-URI modify " SIP/2.0" ";user=phone SIP/2.0"
!
!
```

The above configuration alters the list of allowed / negotiated codecs (along with corresponding preferences) so that:

- Only G.711 A-law, G.711 μ -law, or G.729 / G.729a (not Annex-B) codecs are permitted
- Invite requests to the platform correctly format the request URI to contain the "user=phone" parameter.

Dial Peers

The last part of the configuration handles the core call routing between the CUBE device and both the platform and the CUCM server(s). While dial peer configuration is fairly straightforward, there are some key parameter requirements that must be fulfilled in order to apply the voice classes and behaviours configured in the previous step and to ensure that the signalling from the CUBE device is compliant with the platform requirements.

Configuration of dial peers can be split into four distinct sections, namely:

- i. CUBE device to CUCM
- ii. CUCM to CUBE device
- iii. CUBE device to SIP trunking platform
- iv. SIP trunking platform to CUBE device

On the following page is a sample configuration covering the dial peers that deal with call legs from the CUBE device to CUCM. It is taken from a base configuration for three CUCM servers allowing priority routing for each server.

```
dial-peer voice 1000 voip
description CUBE to CUCM
destination-pattern +44<DDI Number Range>
session protocol sipv2
session target ipv4:<CUCM server 1 IP>
session transport tcp
preference 1
voice-class codec 1
voice-class sip options-keepalive
dtmf-relay rtp-nte
no vad
!
dial-peer voice 1001 voip
description CUBE to CUCM
destination-pattern +44<DDI Number Range>
session protocol sipv2
session target ipv4:<CUCM server 2 IP>
session transport tcp
preference 2
voice-class codec 1
voice-class sip options-keepalive
dtmf-relay rtp-nte
no vad
!
dial-peer voice 1002 voip
description CUBE to CUCM
destination-pattern +44<DDI Number Range>
session protocol sipv2
session target ipv4:<CUCM server 3 IP>
session transport tcp
preference 3
voice-class codec 1
voice-class sip options-keepalive
dtmf-relay rtp-nte
no vad
!
!
```

The key components of this example configuration are highlighted in red for one of the dial-peers. These elements set the following behaviours for calls allocated to the corresponding dial peers:

- Set the signalling to use TCP (rather than the default of UDP). Though not strictly necessary using TCP where possible does have some advantages (see previous configuration for CUCM SIP Trunk Security Profile).
- Sets the call leg to only allow one of the desired / permitted codecs (i.e. G.711 A-law, G.711 μ -law or G.729 / G.729a (without Annex B revisions)) – as defined in the voice classes section.
- Configures the CUBE device to periodically probe the end target device (in this case the individual CUCM server) such that any failed or unresponsive device automatically takes the dial peer out of service for call routing.
- Configures RFC-2833 compliant DTMF signalling as the preferred / chosen signalling method during codec negotiation.
- Disable voice activity detect (VAD) silence suppression to minimise issues with firewalls and other media gateways / border devices.

The following is a sample configuration for the dial peer corresponding to call legs from CUCM to the CUBE device:

```
dial-peer voice 2000 voip
description CUCM to CUBE
session protocol sipv2
session transport tcp
incoming called-number .T
voice-class codec 1
dtmf-relay rtp-nte
no vad
!
```

The key components of this example configuration are highlighted in red. These elements configure the following behaviours for calls allocated to the corresponding dial peer:

- Set the signalling to use TCP (rather than the default of UDP). Though not strictly necessary using TCP where possible does have some advantages (see previous configuration for CUCM SIP Trunk Security Profile).
- Sets the call leg to only allow one of the desired / permitted codec (i.e. G.711 A-law, G.711 μ -law or G.729 / G.729a (without Annex B revisions)) – as defined in the voice classes section.
- Configures RFC-2833 compliant DTMF signalling as the preferred / chosen signalling method during codec negotiation.
- Disable voice activity detect (VAD) silence suppression to minimise issues with firewalls and other media gateways / border devices.

The next section of configuration covers dial-peers corresponding to call legs from the CUBE device to the SIP trunking platform SBC's:

```
dial-peer voice 2010 voip
description CUBE to Provider
preference 1
destination-pattern .T
session protocol sipv2
session target ipv4:<SBC 1 IP>
session transport udp
voice-class codec 1
voice-class sip early-offer forced
voice-class sip profiles 100
voice-class sip options-keepalive
dtmf-relay rtp-nte
no vad
!
dial-peer voice 2020 voip
description CUBE to Provider
preference 2
destination-pattern .T
session protocol sipv2
session target ipv4:<SBC 2 IP>
session transport udp
voice-class codec 1
```



```
voice-class sip early-offer forced
voice-class sip profiles 100
voice-class sip options-keepalive
dtmf-relay rtp-nte
no vad
!
dial-peer voice 2030 voip
description CUBE to Provider
preference 3
destination-pattern .T
session protocol sipv2
session target ipv4:<SBC 3 IP>
session transport udp
voice-class codec 1
voice-class sip early-offer forced
voice-class sip profiles 100
voice-class sip options-keepalive
dtmf-relay rtp-nte
no vad
!
dial-peer voice 2040 voip
description CUBE to Provider
preference 4
destination-pattern .T
session protocol sipv2
session target ipv4:<SBC 4 IP>
session transport udp
voice-class codec 1
voice-class sip early-offer forced
voice-class sip profiles 100
voice-class sip options-keepalive
dtmf-relay rtp-nte
no vad
!
!
```

The key components of this example configuration are highlighted in red. These elements configure the following behaviours for calls allocated to the corresponding dial peer:

- Set the signalling to use UDP which is the SIP trunking platform default transport mechanism.
- Sets the call leg to only allow one of the desired / permitted codecs (i.e. G.711 A-law, G.711 μ -law or G.729 / G.729a (without Annex B revisions)) – as defined in the voice classes section.
- Configures the CUBE device to perform SIP Delayed-Offer to Early-Offer interworking, allowing CUCM to negotiate Early Media on outbound calls (as required by the platform) without forcing on MTP and restricting use to a single G.729a codec.
- Enables the CUBE device to manipulate the outbound SIP signalling to make it conform with platform requirements regarding request URI formatting.
- Configures the CUBE device to periodically probe the end target device (in this case the individual platform SBC's) such that any failed or unresponsive device automatically takes the dial peer out of service for call routing.
- Configures RFC-2833 compliant DTMF signalling as the preferred / chosen signalling method during codec negotiation.
- Disable voice activity detect (VAD) silence suppression to minimise issues with firewalls and other media gateways / border devices.

The final section of CUBE device example configuration covers dial-peers corresponding to call legs from the SIP trunking platform SBC's to the CUBE device:

```
dial-peer voice 1010 voip
description Provider to CUBE
session protocol sipv2
session transport udp
incoming called-number +44<DDI Number Range>
voice-class codec 1
dtmf-relay rtp-nte
no vad
!
```

The key components of this example configuration are highlighted in red. These elements configure the following behaviours for calls allocated to the corresponding dial peer:

- Set the signalling to use UDP which is the SIP trunking platform default transport mechanism.
- Sets the call leg to only allow one of the desired / permitted codecs (i.e. G.711 A-law, G.711 μ -law or G.729 / G.729a (without Annex B revisions)) – as defined in the voice classes section.
- Configures RFC-2833 compliant DTMF signalling as the preferred / chosen signalling method during codec negotiation.
- Disable voice activity detect (VAD) silence suppression to minimise issues with firewalls and other media gateways / border devices.

4 Hardware Resources Required for the Correct Operation of CUCM

In order to successfully place outgoing calls across the BT SIP Trunk platform from CUCM, MTP is required to be configured for some non RFC-2833 DTMF compliant devices. The use of software MTP does not scale well therefore hardware MTP must be used. Cisco IOS Enhanced Software MTP is sufficient for SIP Trunking purposes.

These hardware-based MTP devices (of which Cisco IOS Enhanced Software MTP is classed as hardware-based), should be assigned to the media resources of the device endpoints (to allow local resource use) and not the SIP Trunk.

Furthermore, because of the G.729a mandatory codec support requirement for platform calls, hardware transcoding resource may be required for devices that do not natively support the G.729a codec, such as a software-based T.38 fax solution which supports the G.711 codec only. This hardware transcoding needs to be applied to the media resources of the devices which require transcoding.

Cisco IOS Enhanced Software MTP

The number of concurrent software MTP sessions which a platform can support will depend upon the hardware of the Cisco IOS device being configured. As such, the following configuration should be considered as guidance only. Additionally, each MTP resource can only support a singular codec and therefore multiple profiles must be configured for each and every codec expected to be in use across the BT SIP Trunk platform.

Note: In order to support T.38 faxing an additional codec can (and must) be configured for each MTP profile. This codec is “**pass-through**”, failure to do so will result in T.38 fax calls failing.

Sample configuration for Cisco IOS Enhanced Software MTP is as follows:

```
dspfarm profile 1 mtp
description Soft MTP - G.711ulaw
codec g711ulaw
codec pass-through
maximum sessions software 16
associate application SCCP
!
dspfarm profile 2 mtp
description Soft MTP - G.711alaw
codec g711alaw
codec pass-through
maximum sessions software 16
associate application SCCP
!
dspfarm profile 3 mtp
description Soft MTP - G.729a
codec g729ar8
codec pass-through
maximum sessions software 16
associate application SCCP
```

Cisco IOS Hardware Transcoding

The number of concurrent hardware transcoding sessions which a platform can support will depend upon the hardware of the Cisco IOS device being configured. As such, the following configuration should be considered as guidance only. Furthermore by default a hardware transcoder requires one call leg to be G.711, however to cover all possibilities the following example uses “**Universal transcoding**”. This enables transcoding from any codec to any codec (within the configured codec list), rather than G.711 to any codec which is the default behaviour.

Each hardware transcoding profile must be configured for each and every codec expected to be in use across the BT SIP Trunk platform.

Note: In order to support T.38 faxing an additional codec can (and must) be configured for each hardware transcoder profile. This codec is “**pass-through**”, failure to do so will result in T.38 fax calls failing.

Sample configuration for Cisco IOS Hardware Transcoding is as follows:

```
dspfarm profile 4 transcode universal
description Hardware transcoder
codec g711ulaw
codec g711alaw
codec g729ar8
codec pass-through
maximum sessions 3
associate application SCCP
!
```

5 End Device Specific Parameters Required for Correct Operation

Within the test solution a SIP gateway was configured as an analogue fax gateway and also as a local PSTN gateway (to test for potential migration scenarios). No specific requirements for SIP dial peers were required other than setting the correct DTMF relay and codec parameters (see CUBE device configuration sections).

For typical customer deployment scenarios, however, many solutions use MGCP gateways for PSTN gateways and SCCP for analogue gateways. SCCP gateways DO NOT support standards-based T.38 faxing and so for analogue faxes must be converted to MGCP in order to enable successful faxing. Any MGCP gateways in use require additional configuration to be applied on CUCM and on the MGCP controlled Cisco IOS gateways as well.

CUCM MGCP Gateway Configuration – Product Specific Configuration Layout

The following parameters were changed from default during testing:

Parameter	Default Setting	New Setting
Type of DTMF Relay	Current GW Config	NTE-CA
Modem Passthrough	Enable	Disable
Cisco Fax Relay	Disable	Disable
T38 Fax Relay	Disable	Enable

More detailed information on these changes is as follows:

Type of DTMF Relay

DTMF relay towards the BT SIP Trunk is extremely restrictive (i.e. the use of RFC 2833 compliant signalling is required). Therefore to ensure that CUCM instructs the MGCP gateway to use the correct DTMF signalling the signalling needs to be set under Call Agent control by setting the Type of DTMF Relay parameter to **“NTE-CA”**.

Modem Passthrough

As only T.38 fax support was mandated the potential to use G.711 pass-through for faxing needed to be restricted and therefore Modem Passthrough was set to **“Disable”**.

Cisco Fax Relay

Cisco Fax Relay uses a proprietary signalling mechanism to signal switchover to using Fax Relay and therefore will not interoperate with the BT SIP Trunk platform. Accordingly the capability must be kept disabled by setting the Cisco Fax Relay parameter to **“Disable”** (which is the default setting).

T38 Fax Relay

The BT SIP Trunk platform requires the use of T.38 fax relay to allow faxes to successfully transfer and therefore this capability must be enabled by setting the T38 Fax Relay parameter to **“Enable”**.

IOS MGCP Gateway Configuration

By default a Cisco IOS voice gateway will drop the negotiated fax rate to a rate commensurate with the negotiated voice codec (i.e. 7,200 bps for a G.729a call or 14,400 bps for a G.711 call). This can be overridden using the “**mgcp fax rate <rate>**” command should solution specific configurations require it (optional – use with caution).

Additionally redundancy can also be added to the T.38 fax data stream to counter the effects of lost packets (the important parameter being high speed redundancy) using the “**mgcp fax t38 ls_redundancy <value>**” and “**mgcp fax t38 hs_redundancy <value>**” commands.

As with other devices, the MGCP gateway must also transmit RFC2833 compliant DTMF signalling. By default it does not and an additional capability package must be enabled to do so, this is done with the use of the “**mgcp dtmf-relay voip codec all mode nte-ca**” and “**mgcp package-capability fm-package**” commands.

The following example reflects the Cisco IOS voice gateway configuration that corresponds to the CUCM MGCP configuration, but further expands it to add RFC 2833 compliant DTMF signalling, implement full T.38 fax redundancy and override the negotiated fax rate beyond the default G.729a codec restriction:

```
ccm-manager mgcp
no ccm-manager fax protocol cisco
ccm-manager music-on-hold
ccm-manager config server <ip address list>
ccm-manager config
!
mgcp
mgcp call-agent <ccm server> 2427 service-type mgcp version 0.1
mgcp dtmf-relay voip codec all mode nte-ca
mgcp rtp unreachable timeout 1000 action notify
mgcp package-capability rtp-package
mgcp package-capability sst-package
mgcp package-capability pre-package
mgcp package-capability fm-package
no mgcp package-capability res-package
no mgcp timer receive-rtcp
mgcp sdp simple
mgcp fax rate 14400
mgcp fax t38 ecm
mgcp fax t38 ls_redundancy 5
mgcp fax t38 hs_redundancy 2
!
mgcp profile default
!
!
```

Note: This configuration assumes automatic CUCM configuration rather than manual MGCP configuration via the Cisco IOS voice gateway CLI. Any additional IOS configuration commands that were manually entered are highlighted in red.